MELO M1220
2IN1 MASSAGE HEAD AND VIBRATOR

User manual

CONTROL
1) Hold the middle power button for 3 seconds to turn on.
The vibrator will greet you by lighting up the LEDs.
2) Short presses on the + button to turn on and change the vibration and pulsation rhythms, short presses on the - button to return to the mode.
3) Short presses of the power button switch the motors in the head and the end of the vibrator.
4) Turn it off by long pressing the power button again for 3 seconds.

MAINTENANCE
After each use, rinse the vibrator with lukewarm water and soapy detergent.
You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF
The vibrator is **waterproof**, so maintenance is very easy.
It may get splashed with water, but you can safely immerse it in water and enjoy water play.

LUBRICATION
Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING
The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.
Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

STORAGE
Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS
Vibrator and USB cable for charging.

Růžový slon s. r. o.
Výstavní 1928/9
722 00 Ostrava – Moravská Ostrava, Czech Republic

Potřebujete poradit?
Napište nám na ahoj@flagranti.cz
nebo zavolejte na 555 333 169