WOODOO TOUCH SAKURA JUPITER

User manual

CONTROL
1) The bottom of the vibrator serves as a cover for the batteries.
2) To turn on the vibrator, remove the battery cover, insert one AA battery (not included) and screw the cover back on.
3) Turn the vibrator on by turning the wheel on the battery cover and gradually rotate to regulate the strength of the vibration.

MAINTENANCE
After each use, rinse the vibrator with lukewarm water and soapy detergent.
You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF
The vibrator **is not waterproof or water resistant!**

LUBRICATION
Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING
The vibrator is powered by one AA battery. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE
Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS
Vibrator.

Růžový slon s. r. o.
Výstavní 1928/9
722 00 Ostrava – Moravská Ostrava, Czech Republic

Potřebujete poradit?
Napište nám na ahoj@flagranti.cz
nebo zavolejte na 555 333 169