

BEFORE YOU DIVE IN

1. Unlock the FUN



Press and hold the two buttons for 4 seconds to unlock the toy.

2. Charge MEA

MEA arrives with its battery charged to about 20%. Fully charge MEA to enjoy it longer.

3. Lie back and enjoy!

POWER ME UP!

Place MEA in the Toycase (included).

To charge MEA, connect the USB cable to a USB power plug and the case.

Immediately, the flashing LED light on the outside of the case will indicate that your toy is charging.

MEA needs:

- 4 hours to charge fully

MEA offers:

- 90-120 minutes in the garden of pleasure



WASH ME LUBE ME UP

Clean MEA before and after each use, including the first. Use unscented soap or toy cleaner. The toy is splash-proof. If you like to use lubricant, make sure it is water-based.

PLAY WITH ME

Press the  button for half a second to turn the toy on. Your adventure will automatically start at the third speed. Use the  and  buttons to switch between different speeds and rhythms. To turn the toy off, press the  button again.



REMEMBER ME

Use the memory function to save your favorite speed or pattern. Just press and hold the  button for 2 seconds until your toy buzzes twice. The next time you turn on MEA, you will be taken directly to the setting you chose. To reset it, press and hold the  button until the toy buzzes five times.



DEEP ORGASM PROGRAM

Want to let your imagination run wild and forget everything around you? Then the Deep Orgasm Program is perfect for you. It pleasures you to the fullest all the way until climax, outside of time and space and without haste. The stimulation feels like cunnilingus: subtle and delicate caresses that inevitably lead to a deep, long-lasting, and addictive orgasm.

INTENSE ORGASM PROGRAM

Want to satisfy your desire quickly? Then choose the Intense Orgasm Program for strong, fast suction that leads to a liberating orgasm.

EDGING PROGRAM

Want a big O that's worth the wait? Then you need the Edging Program! Build your desire by pausing just before orgasm and starting all over again. When you finally climax, you'll be overcome by an incredible orgasm like you've never experienced before.



HOW TO USE MEA

01

Go to a place where you feel completely comfortable and won't be disturbed. Hold the toy as shown in the illustration—MEA was designed for you to hold comfortably. Press  to turn MEA on. Place MEA on your external clitoris. The toy's circular tip makes it easy to find the perfect



spot. Can't find it right away? Try spreading your labia slightly with your other hand to expose the clitoris. Then reposition MEA, sit back, relax, and embark on your orgasmic journey.





02


Press  to access deep, cunnilingus-like stimulation, and press  for intense, vibration-like speeds. Keep pressing  to reach the orgasm programs. Once you're about to start these programs, you'll hear a discreet double beep.



03

Let your partner please you with MEA!
How does it feel to give up control and let another person guide you through waves of pleasure?

EXPERIENCE AESTHETICS



CHARGING CASE

MEA's beautiful Toycase protects your toy while harnessing the latest technology: You can charge MEA while it's inside the case via a USB-C port. An LED indicator will show you the charge status. Whether you're traveling or at home, the case looks sleek and luxurious and is the ideal safe place to store MEA.

WHAT'S BEHIND MEA'S DESIGN?



MEA's ergonomic shape fits comfortably in your hand and the finger recess lets you press all the buttons easily for a simple and intuitive experience.

No matter the size, shape, or position of your clitoris, MEA's rounded opening fits!