THE GIFT SET JE JOUE
THE NAUGHTY COLLECTION

User manual

CONTROL
1) Hold the + button for 2 seconds to turn on the stimulator.
2) Short presses of this button increase the intensity of the vibration, short presses of the - button decrease it back.
3) Short presses of the middle button with the wave symbol change the individual vibration and pulsation rhythms.
4) Hold the button - for 2 seconds to switch off the stimulator.

MAINTENANCE
After each use, rinse the stimulator with lukewarm water and soapy detergent.
You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF
The stimulator is **waterproof**, so maintenance is very easy.
It may get splashed with water, but you can safely immerse it in water and enjoy water play.

LUBRICATION
Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING
The stimulator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.
Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

STORAGE
Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS
In the package you will find the stimulator, task cards, satin blindfold, massage candle and USB cable for charging.

Růžový slon s. r. o.
Výstavní 1928/9
722 00 Ostrava – Moravská Ostrava, Czech Republic

Potřebujete poradit?
Napište nám na ahoj@flagranti.cz
nebo zavolejte na 555 333 169